

CALUMET
PHOTOGRAPHIC
IT'S WHERE THE PROS GO

U.S.A. 630.860.7447 x2258
 United Kingdom 08000 964396
 Germany 040 4231600
 Belgium +31 20-697-7171
 Netherlands 020-697-7171

Operating Instructions

CALUMET SPRINT COLLAPSIBLE HAND CART

The Sprint cart is a collapsible, lightweight hand cart that provides you with convenient transport of equipment weighing up to 200 pounds. It is easy to set up and fold for storage. Its rubber wheels offers smooth movement and a very tight turning radius in tight quarters. **MF5003**

HOW TO UNFOLD



The collapsed cart must be in the upright position and clear of any obstruction before opening. Depress the yellow button on the top/center of the crossbar and pull up on the top handle until it locks into position.



Using your foot or hand, lower the front metal platform. Wheels will simultaneously swing out into their operating position.

HOW TO COLLAPSE



The cart must be in the upright position and clear of any obstruction before collapsing. Press the yellow button on the top/center of the crossbar and push down on the top handle until it is completely collapsed. Do not close platform before lowering handle.



Using your foot or hand, lift the platform up to the folded position. If you are using your hand, make sure that your fingers are not between the platform and cart when folding.

CALUMET ***Runner*** *sprint* Collapsible Hand Cart
C A R T S